

WIRELESS FLEX™ / FLEXMAX™

REMOTE-CONTROLLED LIFTING WITH CONTROLS AT EACH COLUMN

Unmatched lifting versatility and flexibility with the mobility to monitor and adjust your columns anywhere in your shop by following simple set up commands.

Save critical set up time on every lift by not waiting at each column to sync.

Remote control auto detects and connects when communicating to the columns. Handheld control allows user to move around vehicle and observe the entire bay during operation. **Premium FLEXMAX lifts** provide the same remote-controlled flexibility plus added operational controls at each column giving technicians the choice to work in the most comfortable, productive and efficient way possible.

POWERED BY

RedFire
LIFT UP TO 60,000 KG.



FLEXMAX
7500kg. capacity column

Shown: M110212Y-AU

MODEL FEATURES:

**Column capacity at 7500kg.
in configurations of two, four, six or eight columns**



Ergonomic, wireless hand-held remote control walks the technician through the system set up. Status lights indicate standby or paired columns.

Controller includes:

- On/off power button with info screen
- 2-speed joystick control with convenient auto resume
- Single lower-to-lock button with E-stop control
- Remote battery indicator
- Press Protect™ eliminates accidental button presses
- Audible warning when operator is out of range
- 99 system IDs to eliminate communication interference
- Height and weight digital display gauge displays
- Software upgrades can be made wirelessly



FLEXMAX single column controls allow user with remote to select and change column groups and cycle lifts from any column. Includes large screen designed for the toughest shop.



Environmentally-friendly:

- Surface mounted and portable - no excavation or site prep
- Optional high efficiency LED lighting
- Compatible with all bio fluid hydraulic oils
- More than 98% recyclable



Battery operated with on-board charger - no power cords to clutter up the service bay. Batteries purchased separately for international use.


Inverted hydraulic cylinder rod located inside the carriage, protects chrome piston rod from debris and damage.

Easy to move adjustable forks improve set up time. Adjustment range: 241mm to 559mm

Spring loaded steering and braking system eliminates the need to manually operate the jacks. Prevents movement on sloped floors.

Forklift pockets provide convenient way to relocate columns within your shop.

Rubber-coated steel wheels easily roll over dirt and debris. Wheels automatically retract under load.



Exclusive LOCK LIGHT™ indicates when a column



WATCH THE PRODUCT VIDEO
See how fast and easy it is to set up and operate FLEX lifts



FLEX / FLEX MAX 7500kg. COLUMN CAPACITY

MODEL	M110212Y-AU	
Column configuration*	4	6
Capacity per set	30,000 kg.	45,000 kg.
Rise	1760 mm	
Column width	1092 mm	
Wheel Rim Size	228 to 610 mm	
Clearance / fork to column	254 mm	
Speed of rise	68 seconds	
Charging voltage	110v-240v charger (2.5 amps max.)	

* Two, four, six and eight column configurations are available.